

Product Modification Notice

#18-CORP-06

Date: July 19, 2018
To: Lumenera Customers
From: Lumenera Corporation, Product Management
Re: **Mandatory Driver Update**

Due to a change in third party component availability, Lumenera will be issuing a mandatory driver update for certain USB 2.0 cameras.

- Lu10x(all variants)
- Lu16x (all variants)
- Lu17x (all variants)
- Lu20x (all variants)
- Lu37x (all variants)
- Lu117x (all variants)

The hardware revision will occur over time as current inventory is consumed.

Lucam Software and Software Development Kit Ver. 6.8.2 is available for download from the Lumenera website.

- [Lucam Software and Software Development Kit Ver. 6.8.2 - Download](#)

Lucam Software and Software Development Kit Ver. 6.8.2 is fully backward compatible and will support current and previous hardware revisions.

To identify hardware versions, a change to the camera LED indicator color has been made. The LED indicator is located on the rear of the camera enclosure between the the USB port and the power supply connector. The updated colors are as follows:

	LED Indicator Color	Driver Version
Old Hardware Rev.	Yellow	Ver. 6.8.1 and earlier
New Hardware Rev.	Green	Ver. 6.8.2

Questions?

Please contact your Lumenera Representative by phone at +1 613-736-4077.

