



PRODUCT MODIFICATION NOTICE FOR LUMENERA NETWORK CAMERAS

New rugged molded tripod mount improves reliability and ease of use

March 5, 2009 – Lumenera Corporation, www.lumenera.com, a leading manufacturer and developer of high performance digital cameras and custom imaging solutions for scientific, industrial, and surveillance markets, today issued a product modification notice for its network camera line.

Effective late March 2009, Lumenera will begin shipping network cameras with a new and improved molded tripod mount. This change will affect all Le-series and Li-series network cameras, except the Le259, Le11059 and their variants.

The new tripod mount is formed out of rugged molded black ABS plastic, and uses a 1/4 inch diameter 20 threads per inch screw (1/4"-20) to securely mount the camera to an enclosure, wall bracket or standard photography tripod. A threaded metal insert mates with the 1/4"-20 fastener, while a second clear hole accepts the alignment pin found in most tripod mounts designed for photography. Four metal screws fasten the tripod mount to the track on the camera body.

To order additional tripod mounts use order part number Le906B. The previous Le906 tripod mount (aluminum part with 4 nylon screws) will be discontinued.

For any custom or legacy requirements, and/or more information, contact Lumenera at securitysales@lumenera.com.